


DPA 5 Quickstart Guide




1



2




5




3

3



3

4



Instructions:

- 1 Install RP1210-compliant PC drivers from the CD.
The latest RP1210-compliant PC Drivers can always be found at <http://www.dgtech.com>
- 2 After rebooting, you will be prompted to check for updates. Connect to the Internet and press "Continue". Then press the "Check for Updates" button. If there are updates (red), press the "Download" button. DG Update will download and start the installation
- 3 Using the USB cable, connect the DPA to your PC. Connect the vehicle cable to the DPA.
- 4 Make certain to first connect the vehicle cable to the DPA as stated in 3 above.
Finally, connect the other end of the vehicle cable to the vehicle's diagnostic port
- 5 Configure your RP1210-compliant diagnostic application to use the DPA. The "DPA User Manual" contains information for configuring many of the "common" applications. If your application is not covered in the manual, consult the documentation that came with your application on how to configure for RP1210-compliant adapters.